



D-BOX



23" POWER RECLINER SEAT

POWER RECLINER LOVESEAT


23" POWER LOUNGE CHAIR




30" POWER RECLINER SEAT

POWER RECLINER APARTEMENT SOFA


30" POWER RECLINER LOUNGE CHAIR




3 actuators




4 actuators




4 actuators



3 actuators



4 actuators



4 actuators

MULTIPLE SEATS

Leave a clearance of 4" between each D-BOX chair to not block the range of motion.

If the chair is near a wall, allow 6" of clearance.

*Up totwenty (20) seats can be connected to the HaptiSync Hub.

